

Cross Connects and Endpoints Tutorial

Goal: Gain a better understanding on how you will use Cross connects, Connections and Endpoints to use the LANforge CLI scripts knowlegably.

Creating connections in the LANforgeGUI implies creating endpoints. These endpoint entities are created with predictable names and are usually created in pairs. Understanding these naming conventions and how they are created is fundamental to your proficiency with creating connections with LANforge CLI scripts.



Most examples in our cookbooks assume a dual-ended connection, also known as a *cross-connect* or abbreviated as *CX*.

Building Endpoints and Connections

Let's follow the creation of a Connection:

<u>\$</u>	tutorial-ex - C	reate/Modify Cross Connect	
+ All	Display	Sync Batch-Create	Apply OK Cancel
CX Name: CX Type:	Cross-Connect tutorial-cx LANforge / UDP		▼
Resource: Port:	Endpoint A 1 (jedtest) 4 (sta301)	Endpoint B (jedtest) (teth1)	•
Min Tx Rate:	New Modem (56 Kbps)	 ✓ New Modem (56 Kbps) ✓ Same 	•
Max Tx Rate: Min PDU Size:	AUTO		• •
Max PDU Size: IP ToS:	Same Best Effort (0)	✓ Same✓ Best Effort (0)	v
Pkts To Send:	Infinite	▼ Infinite	•

Using a terminal on the LANforge machine, we look at the /home/lanforge/DB/DFLT/endps.db file and inspect the commands issued that create that connection:

```
lanforge@jedtest ~/DB/DFLT
> grep 'tutorial[^ ]*' *db
endp.db:add_endp tutorial-cx-A 1 1 sta301 lf_udp -1 N0 56000 0 N0 -1 0 INCREASING NO 32 0 0
endp.db: set_endp_flag tutorial-cx-A ReplayOverwriteDstMac 0
endp.db: set_endp_details tutorial-cx-A 0 0 4294967295 0 '00 90 0b 29 06 f9 ' 0 0 0 0 10000 0 NA NA NA 0.0.0.0 0
endp.db: set_endp_quiesce tutorial-cx-A 3
endp.db: set_endp_addr tutorial-cx-A '00 0e 8e 24 1f 5b ' AUTO 0 0
endp.db: set_endp_flag tutorial-cx-A ReplayLoop 0
endp.db: set_endp_flag tutorial-cx-A EnableTcpNodelay 0
endp.db: set_endp_flag tutorial-cx-A EnableRndSrcIP 0
endp.db: set_endp_flag tutorial-cx-A EnableConcurrentSrcIP 0
endp.db: set_endp_flag tutorial-cx-A EnableLinearSrcIP 0
endp.db: set_endp_flag tutorial-cx-A EnableLinearSrcIPPort 0
endp.db: set_endp_flag tutorial-cx-A QuiesceAfterRange 0
endp.db: set_endp_tos tutorial-cx-A DONT-SET 0
endp.db:set_script tutorial-cx-A NA NA NONE 'NA' 0 0
endp.db: set_endp_proxy tutorial-cx-A NO
endp.db:rm_thresholds tutorial-cx-A all
endp.db:set_endp_report_timer tutorial-cx-A 5000
endp.db: set_endp_flag tutorial-cx-A ClearPortOnStart 0
endp.db: set_endp_flag tutorial-cx-B ReplayOverwriteDstMac 0
endp.db: set_endp_details tutorial-cx-B 0 0 4294967295 0 '00 0e 8e 24 1f 5b ' 0 0 0 0 10000 0 NA NA NA 0.0.0.0 0
endp.db: set_endp_quiesce tutorial-cx-B 3
endp.db: set_endp_addr tutorial-cx-B '00 90 0b 29 06 f9 ' AUTO 0 0
endp.db: set_endp_flag tutorial-cx-B ReplayLoop 0
endp.db: set_endp_flag tutorial-cx-B EnableTcpNodelay 0
endp.db: set_endp_flag tutorial-cx-B EnableConcurrentSrcIP 0
endp.db: set_endp_flag tutorial-cx-B EnableLinearSrcIP 0
endp.db: set_endp_flag tutorial-cx-B EnableLinearSrcIPPort 0
endp.db: set_endp_flag tutorial-cx-B QuiesceAfterDuration 0
endp.db: set_endp_tos tutorial-cx-B DONT-SET 0
endp.db:set_script tutorial-cx-B NA NA NONE 'NA' 0 0
endp.db: set_endp_proxy tutorial-cx-B NO
endp.db:rm_thresholds tutorial-cx-B all
endp.db:set_endp_report_timer tutorial-cx-B 5000
endp.db: set_endp_flag tutorial-cx-B ClearPortOnStart 0
tst_mgr.db:add_cx tutorial-cx default_tm tutorial-cx-A tutorial-cx-B
tst_mgr.db:set_cx_report_timer default_tm tutorial-cx 5000 cxonly
lanforge@jedtest ~/DB/DFLT
>
```

That's a lot of commands. We will point out what is particularly necessary when using our Perl scripts.

Endpoints and Connections Naming Convention

The connection we created above is named **tutorial-cx**. Two endpoints also have names, tutorial-cx-A and tutorial-cx-B. The A-side of a connection is always managed. A B-side endpoint may be unmanaged. When you write CLI scripts that create connections, name your endpoints using a similar convention.

Endpoints are Created First

We can use the lf_firemod.pl script to create endpoints and a cross connect in this order:

```
$ ./lf_firemod.pl --action create_endp --endp_name tutorial2-cx-A \
         --speed 256000 --endp_type lf_tcp --port_name sta301
$ ./lf_firemod.pl --action create_endp --endp_name tutorial2-cx-B \
         --speed 256000 --endp_type lf_tcp --port_name eth1
$ ./lf_firemod.pl --action create_cx --cx_name tutorial2-cx \
         --cx_endps tutorial2-cx-A,tutorial2-cx-B
```

We can see the results of those script commands in our Layer-3 and L3 Endps tabs:

<u>\$</u>					LAN	forge Ma	mager Vers	sion((5.3.3)						-0×
Control Reporting Tear-Off Info Plugins															
							Stop All		Res	start Ma	nager		Refres		HELP
Stop All Restart Manager Refresh HELP															
Layer-4 Test Mgr Test Group Resource Mgr Event Log Alerts Port Mgr Messages															
Status Layer-3 L3 Endps Armageddon WanLinks Attenuators File-IO															
Rpt Timer: default (5 s) Image Go Test Manager all Image Select All Start Stop Quiesce Clear															
View	View 0 - 200														
Cross Connects for Selected Test Manager															
Name	т	ype	State		kt Rx A	Pkt Rx B	B Bps	Dv A		Ppp	Rx B	Py Dro	p % A Rx Dro	0 04 D T	ron Plet
Name		ype	State		KL DA A	FRUNKI	b bbs	DA P	`	pha	NA D	NA DIO	p % A KK DIO	P 70 D L	TOP FRE
cx-sta300	LF/	UDP RU	un	33	,823,148	33,802,2	88	767	7,489		767,016		0.066 (0.113	22,4
tutorial-cx		UDP St			0		0		0		0		0	0	
tutorial2-cx	LF/	TCP St	opped		0		0		0		0		0	0	
Logged in to: 192.168.100.26:4002 as: Admin															
	:0: 192.	168.10	0.26:40	102 8	as: Admin			_							
L3 Endps															
Stop All Restart Manager Refresh HELP															
Min PDU Size	AUTO		-	Go	Max PDU	J Size Same	2		Go		Start	Stop	Quiesce	Clear	
MIN Tx Rate	Rate New Modem (56 Kbps) - GO MAX TX R		Rate Same	6	•	Go									
1.6	0 400									Displa	y Cr <u>e</u> ate	Modi	y Batch Mod	dify	Delete
View	0 - 400		-	Go											
All Endpoints															
								Т	x Rate					Rx Rat	0
Name	e	EID	Run	Mng	Scr	ript	Tx Rate		1 min)		Tx Rate	LL	Rx Rate	(1 min	
cx-sta300-A		1.1.2.1	~	~	None		767,8	01	7	68,102	703	3,626	767,489	2	767,905
cx-sta300-A		1.1.1.2.1		V	None		767,9			58,102		1,578	767,016		768,124
tutorial-cx-A		1.1.4.3		~	None			0		0		0	((
tutorial-cx-B		1.1.1.4		~	None			0		0		0	(-	C
tutorial2-cx-		1.1.4.5			None			0		0		0	(C
tutorial2-cx-		1.1.1.6		~	None			0		0		0	()	C
															•
														• •	
i Multiple	Window	Ne can l	ha dica	lavod	lusing the	Toar Off	menu								
Multiple Windows can be displayed using the Tear Offs menu.															

i Clicking on the Layer-3 connection automatically highlights the two endpoints.

Starting and Stopping: Connections have State

When a connection is first created, it is STOPPED. When you start it, it becomes RUNNING. When you set a connection to STOPPED, both endpoints immediately stop sending and recieving. That can have a consequence of leaving unacknowledged packets in flight. The safest way is to QUIECE the connection, which first stops the endpoints transmitting, waits a short time, and then stops the endpoints from recieving.

When there is just one Endpoint

Normally, if you see one endpoint, it should only be a multicast endpoint. A single endpoint can be seen in these situations:

- You have paused between creating the first and second endpoint for a connection. Continue working.
- Created by a script mistakenly, through a typo or other misconfiguration
- Left over from an interrupted script that deleted the cross-connect and one of two endpoints

A single endpoint is not an illegal entity, but lonely endpoints can add confusion. If you find endpoints that do not match any existing connections, we suggest deleting them.

A Cross-Connect can be *one-sided*, that is, have one *unmanaged* endpoint. The A side endpoint is a LANforge managed port transmitting to another device that's not a LANforge machine. Some connection types create this style of endpoint pairs, like **File-endpoints** and **Layer-4 connections**.

Multicast

Multicast endpoints are created differently both in the GUI and in the CLI scripting environment. This tutorial does not focus on multicast, but see the section Creating Endpoints section of Creating Connections with FIREMod Script and the chapter on WiFi Multicast Download.

Candela Technologies, Inc., 2417 Main Street, Suite 201, Ferndale, WA 98248, USA www.candelatech.com | sales@candelatech.com | +1.360.380.1618